

Stückliste für Vorschubsteuerung Opti Bf20						
ANZAHL	TYP	NAME	TEXT 1	TEXT 2	GEHÄUSE	ART.NR.
7	BR	BR1, BR2, BR3, BR4, BR5, BR6, BR7			BR4	
1	EC	C1	470µF	63V	ECD10RM2	RAD105 470/63
2	C	C2, C4	100nF	50V	C7,5x2,5	X7R-5 100N
1	EC	C5	2200µF	50V	ECD16RM2	RAD105 2.200/50
1	C	CX	100nF-1µF	50V	C7,5x4,5	MKS-2 1,0µ
4	D	D1, D2, D3, D4	1N4148		D4	1N4148
1	LÖTKLEMME3POL	DS			LÖTKLEMME3POL	AKL101-03
7	LÖTKLEMME2POL	ESL, ESR, TL, TR, X-15V, X-24V, XMotor			LÖTKLEMME2POL	AKL101-02
1	BG	GL1			KB10	B80C1500RUND
1	BG	GL2			KBU802G	KBU8B
1	7812	IC1			TO220AB	µA7812
1	555	IC2			DIL8	NE555DIP
4	INTERTEC-TA	KL, KR, KTL, KTR			INTERTEC-TA	G5V-1 12V
2	REL28B1	MKL, MKR			REL28U1	Fin 40.529 12V
1	R	R2	10K		R4	METALL10K
1	SOCKEL-DIL8	S1			SOCKEL-DIL8	GS8P
1	HEXFET	T1	IRF054N		TO247AC	IRFP054N
1	TP	TP1	10K		TP2	P4M-LIN-10K
1	TP	TP2	1K		TP2	64W-1K